

TOP OF SIGN

GROOVE IN EDGE

CAPTIVE NUTS
IN EDGE GROOVE

DRILL HERE
(1 OF 4)

DRILL HERE
(2 OF 4)

FLAT-MOUNT INSTRUCTIONS:

1. DECIDE IF BRACKETS WILL BE ARRANGED VERTICALLY OR HORIZONTALLY.
(ALLOW ROOM TO INSERT AND TO TIGHTEN SCREWS INTO EDGE OF FRAME.)
2. PLACE TEMPLATE AT DESIRED SIGN INSTALLATION LOCATION. MARK AND DRILL (4) MOUNTING HOLES AS SHOWN:
-1, 2, 3, & 4 FOR VERTICAL BRACKETS
-A, B, C, & D FOR HORIZONTAL BRACKETS
(USE APPROPRIATE DRILL BIT FOR ANCHORING METHOD:
-1/4-INCH FOR INCLUDED PLASTIC DRYWALL / CONCRETE ANCHORS
-3/32-INCH FOR WOOD SURFACE - (OTHER SIZE FOR INSTALLER-PROVIDED ANCHORS)

CENTER LINE

CENTER LINE

ALTERNATE HORIZONTAL BRACKET LOCATION


ALTERNATE HORIZONTAL BRACKET LOCATION

9.540

3. MOUNT BRACKETS TO WALL WITH (4) SCREWS/ANCHORS.
4. MOUNT SIGN TO BRACKETS WITH (4) #8-32 X 1/4-INCH SCREWS.

DRILL HERE
(3 OF 4)

DRILL HERE
(4 OF 4)

DATE: AUGUST 7, 2009	CORNELL PART NO: D-SN420-MTW
TITLE: SERIES SN-LM42 GLOW SIGNS WALL-MOUNT TEMPLATE	
	
CORNELL Communications, Inc. sales@cornell.com 414-351-4660 Web: www.cornell.com 414-351-4657(fax)	

BOT. OF SIGN

GROOVE IN EDGE

14.000