



CORNELL

Emergency Response Systems

A-1806D, A-1808D and A-1809 Keypad Station



A-1806

CORNELL remote keypad stations allow quick access for authorized personnel.

1-800-558-8957

Operation: Model A-1806D (Arm, Disarm & Exit Delay) Enter the 1 to 6-digit access code. The yellow LED will flash 3 times. Press the * key to disarm the zone, the # key to arm the zone, or the 0 key to initiate time delay.

Model A-1808D (Exit Delay only) Enter the 1 to 6 digit access code and the 0 key to initiate the delay.

Model A-1809 can be custom programmed and includes one form-C dry contact.

Indicators: Red LED -system armed; Green LED - system unarmed; Yellow LED - exit delay mode. Two gang satin stainless steel plate. Fits standard 2-gang electrical box.

Engineering Specifications

The contractor shall furnish and install a CORNELL remote zone control keypad. The faceplate shall be a standard two-gang stainless steel plate. The keypad shall be micro-controller based. The micro-controller shall have built-in watchdog timer. LED indicators (red, green, yellow) shall be utilized for long life; incandescent lamps are not acceptable. Unit shall be user programmable entirely from the keypad. Unit shall accept any 1-6 digit access code. Programming shall be preserved during power failure. Unit shall be operated on 12 VDC. Power consumption shall be less than 20mA.

CORNELL COMMUNICATIONS, INC.

Milwaukee, Wisconsin USA - 800-558-8957 - 414-351-4660 - Fax 414-351-4657
www.cornell.com - sales@cornell.com

