



Rescue Assistance Series 4100

Operation Instructions

GENERAL

The *CORNELL* Rescue Assistance Systems provides audible and visual indication of a call for assistance at both the call station and the annunciator.

CALL STATION

1. In an evacuation situation the call is initiated at the call station by depressing the call button.
2. The call is confirmed by:
 - a. the button lighting and
 - b. a single tone is heard at the call station
3. When the call is confirmed by the person at the control panel, the call station action will be:
 - a. the lighted button will flash
 - b. the buzzer will give an intermittent tone

CONTROL PANEL

1. An incoming call is indicated by:
 - a. the indicator light on the zone button will illuminate
 - b. and the tone will sound intermittently
2. When the control panel operator acknowledges the call by pressing the zone button:

This action will cause:

 - a. the zone indicator light to flash
 - b. and the tone will stop
3. When the emergency has been resolved, the zone is reset to standby by pressing the zone button(s) where the indicator light is flashing. This will turn off the indicator light.
4. Optional access to a public telephone system shall be provided when specified.

12/03

