



**NOTES:**

THE VERSAPAGE INTERFACE, REQUIRES A 22GA WIRE FROM EACH MONITORED TERMINAL OF THE A-4000 SERIES ANNUNCIATOR, AS SHOWN ABOVE. THE (+VDC) TERMINAL, ON THE CORNELL ANNUNCIATOR, PROVIDES COMMON SYSTEM VOLTAGE TO THE (-) TERMINALS ON THE VERSAPAGE INTERFACE. THE MONITORED POINTS ON THE CORNELL ANNUNCIATOR, IN THE CONFIGURATION SHOWN, PROVIDE THE NEG (-) CONNECTION TO THE (+) TERMINALS ON THE VERSAPAGE INTERFACE.

FOR ADDITIONAL SYSTEM MONITORING AND CONNECTION OPTIONS, PLEASE CONSULT THE INSTALLATION MANUAL ON OUR WEBSITE .

