



CORNELL

Emergency Response Systems

DS-110 Duty Station Single Status



DS-110

CORNELL DS-110 Duty Station offers immediate annunciation of any call on the system.

1-800-558-8957

Operation/Description

Function - Duty Station for Single Status Systems.

Call Indication - Flashing or Steady Red LED Indication and Pulsing Tone. Switch Function. Manual High or Low Volume Tone.

Terminations - Pigtailed for field wiring.

Finish - Satin stainless steel plate.

Mounting - Flush to fit standard outlet box with single gang plaster ring or surface to fit Wiremold box 5748 or equal.

Engineers Specifications

The duty station shall be CORNELL Model DS-110. Incoming emergency calls shall be indicated by a (steady) (flashing) red LED indicator and pulsing tone. The station shall have a manual switch for High-Low volume. The station shall fit on a standard single gang plaster ring or Wiremold 5748 surface box or equal. Minimum depth shall be 1 3/4". Visual indicators shall be LED's. Incandescent lamps not accepted. Terminations for field wiring shall be pigtailed.

CORNELL COMMUNICATIONS, INC.

Milwaukee, Wisconsin USA - 800-558-8957 - 414-351-4660 - Fax 414-351-4657
www.cornell.com - sales@cornell.com

