



CORNELL

Emergency Response Systems

A-4003/A-4006 Annunciator Station Three and Six Station



A-4006

CORNELL Annunciator Station offers cost effective way to announce emergency situations for small systems.

1-800-558-8957

Operation/Description

Function - Indicates incoming calls for use in systems requiring only three or six indicators.

Call Indication - red LED indicators and pulsating electronic tone.

Controls - Standby/Resound switch.

Finish - Satin stainless steel plate with permanent silk-screened designations.

Mounting - Flush - two-gang (A-4003) or three-gang (A-4006) plaster ring or equal. Surface mounting is Wiremold 5744-S two- or three-gang as required. The minimum depth required is 2".

Latching circuit available only on six station, Model A-4006L.

Engineers Specifications

Provide and install a Cornell A-4003 (A-4006) annunciator. Faceplate shall be satin stainless steel with silk-screened designations. Call indicator shall be red LEDs and pulsating electronic tone. Standby/Resound switch shall normally be in the Standby position. When a call comes in the light will turn on and a pulsating tone will be heard. Placing the switch in the Resound position will cancel the tone only until the call is canceled. When the call is canceled the tone will start, reminding the operator to reset the switch to the Standby position. Unit shall be flush or surface mounted.

