



Satellite Stations – HWN7624AA / HWN7625AA

Description

The HWN7624AA and HWN7625AA Satellite Stations are bedside call devices used in conjunction with a wall-mounted patient station (HWN7630AA) to provide a cost effective solution for multi-bed rooms. Designed for simplicity and low cost, the HWN7624AA unit is a call cord receptacle mounted on a stainless steel faceplate in a single-gang, wall-mounted configuration, which provides a patient call function and an emergency cord pullout function when used with a standard HWN7630AA Patient Station. The HWN7625AA Satellite Station, in addition to the call cord receptacle, includes a membrane switch pad with ASSIST and RESET switch functions and a call LED indicator, also in a single-gang package. This device, once installed, looks and operates the same as the host HWN7630AA patient station. Each Satellite Station accepts one of three types of call cord devices: HAN7608AA, HAN7609AA or HAN7610AA.



HWN7625AA

Features

- Does not require additional address position in room map
- Membrane switch pad and tri-color LED indicator (HWN7625AA)
- Safety call cord disconnect socket (places call when removed)
- Ease of Operation – The patient simply presses the button on the end of the Call Cord to activate the visual and audible (sounders) output devices programmed to this station. Calls placed must be cancelled at the Patient or Satellite station, assuring the patient of prompt attention by the staff.
- Designed for simple installation and maintenance
- Single- or dual-bed operation

Model Identification

HWN7624AA – Satellite Station, call cord receptacle on single-gang brushed stainless steel faceplate
 HWN7625AA – Satellite Station, single-gang with membrane switch pad and call cord receptacle
 HFN7601AA – Faceplate, single-gang, brushed stainless steel (required for HWN7625AA only)

Technical Data

Input Power: 12 VDC, 1 ma DC or less standby current per station

Wall Box

Each Satellite Station requires a standard 4” square electrical back box, 2 1/8” deep minimum, with a one gang 3/4” deep plaster ring, or a one-gang masonry box, 3 1/2” deep, or equivalent.

Architect’s Specifications

The Satellite Station shall be a single-gang, wall-mounted call device, model HWN7624AA (includes stainless steel faceplate), or model HWN7625AA to be installed with a model HFN7601AA single-gang, brushed stainless steel faceplate. The Satellite Station front panel shall include a safety-disconnect call cord socket (HWN7624AA and HWN7625AA) and a membrane switch pad (HWN7625AA only) with ASSIST and RESET switches and a CALL LED indicator. Each of the Satellite Stations shall accept any of three types of call cord devices: HAN7608AA, HAN7609AA or HAN7610AA.

Rev 4/05

CORNELL COMMUNICATIONS, INC.

Milwaukee, Wisconsin USA • 800-558-8957 • 414-351-4660 • Fax 414-351-4657
 www.cornell.com • sales@cornell.com

