



CORNELL

Emergency Response Systems

A-1801 Time Delay Remote Control



A-1801

CORNELL A-1801 Remote Zone Controls with Time Delay offer alarm-free access, plus automatic reset.

1-800-558-8957

Operation: A-1801 Remote Zone Controls with Time Delay provide authorized personnel with alarm-free access to individual zones in the Series A-1000 Door Monitor System. Disarming is accomplished via key; the zone automatically resets to armed status after a preset time delay.

Description: Each station features a red LED to indicate armed status when lit. Single-gang stainless steel faceplate suitable for flush or surface mounting.

Engineering Specifications:

The contractor shall install CORNELL A-1801 Zone Control Stations with Time Delay as indicated on the plans for use with the Series A-1000 Door Monitor System. Each station shall provide alarm-free access to authorized individuals using a key for temporary control disarming. Automatic reset shall follow a preset time delay. Each single-gang stainless steel station suitable for (flush) (surface) mounting shall feature a key switch for disarming and a red LED to indicate armed status when lit. Power shall be supplied via the Series A-1000 master panel at 12 volts DC, regulated. Current is 17mA when zone is armed.

CORNELL COMMUNICATIONS, INC.

Milwaukee, Wisconsin USA - 800-558-8957 - 414-351-4660 - Fax 414-351-4657
www.cornell.com - sales@cornell.com

