



**CORNELL**

Emergency Response Systems

## A-1800 Remote Zone Control



**A-1800**

***CORNELL A-1800 Remote Zone Controls provide convenient access for authorized personnel.***

**1-800-558-8957**

**Operation:** A-1800 Remote Zone Control stations provide authorized personnel with access to doors controlled by the Series A-1000 Door Monitor System. Arm and disarm functions are manually controlled via toggle switch and key.

**Description:** Each station features one red and one green LED. Arm and disarm functions are operable via spring-return, center-off toggle switch when key switch is in "enable" position. Stations feature single-gang stainless steel faceplate with silk-screened designations. They may be flush mounted on standard outlet boxes with single-gang rings, or surface mounted on Wiremold 5748 or equal with a depth requirement of 1-3/4".

### **Engineering Specifications**

The contractor shall install CORNELL A-1800 Zone Control Stations for authorized access to individual doors in the Series A-1000 Door Monitor System. Each single-gang stainless steel station suitable for (flush) (surface) mounting shall feature a red and a green LED, with green indicating unarmed status, red indicating armed and flashing red indicating alarm condition. Key switch and spring-return, center-off toggle switch shall be standard, with arm and disarm functions controllable only when key switch is in "enable" position. Power shall be supplied via the Series A-1000 master panel at 12 volts DC, regulated. Current is 17mA per station.

