



**CORNELL**

Emergency Response Systems

# VersaPage™

Modular Paging Interface



VersaPage™ is the Complete Solution for Direct Messaging to Staff When Emergencies Arise or Assistance is Needed.

**NEW!**

Data Logging & Documentation now Included

Choose VersaPage™ for your facility today.

Whether you wish to add it to your current system or include paging as part of a new system, CORNELL can meet your unique requirements.

**NEW from CORNELL is the VersaPage™ Desktop PC Paging System Software\***  
Any desktop PC computer can instantly notify in-house pagers, send a text message to a cell phone or send an e-mail to an individual or group all at once!

\*Desktop System designed for Windows XP and Vista only. Requires Outlook for e-mail or text messages and will not function on thin network client systems

## Features & Benefits of a VersaPage™ system from CORNELL:

Easy & Quick Installation  
Minimal Wiring Required  
Simple to Operate and Train Staff  
Multiple Product Integration

Discrete Communication  
Existing Systems can be Upgraded  
Flexible System Design  
Saves Valuable Response Time

## System Components

MODEL #	DESCRIPTION
PI-9064U	Paging Interface Universal - The paging interface unit has the ability to monitor signal type, location and event code while sending information to a database and transmitter. Reporting and programming are accessed using a web browser program, connecting to an IP address. 12 VDC power and data cable are included.
TR-9010-W2	2 Watt Paging Transmitter including 1/4 wave antenna providing from 0.25 to 0.5 miles radius of horizontal coverage. Includes RS-232 cable.
TR-9010-W5	5 Watt Paging Transmitter including 1/4 wave antenna providing from 0.5 to 1.0 miles radius of horizontal coverage. Includes RS-232 cable.
PP-9000-AW2	Pocket Pager for 2 Watt System
PP-9000-AW5	Pocket Pager for 5 Watt System
SF-9010	VersaPage™ Desktop PC Paging System Software for one (1) PC
SF-9010N	VersaPage™ Desktop PC Paging System Software for MULTIPLE PC's

**CORNELL COMMUNICATIONS, INC.**

Milwaukee, Wisconsin USA • 800-558-8957 • 414-351-4660 • Fax 414-351-4657  
www.cornell.com • sales@cornell.com



D9000  
100325