



**CORNELL**

Emergency Response Systems

## **E-107 Check In Station** **Push Button, Single-Gang**



**E-107**

***CORNELL's E-107 Check In Station offers easy check in button.***

**1-800-558-8957**

**Operation:** Used with the A-4000 series annunciator panel as a "check-in" room station for senior housing. Pushing the "check in" button activates a light at the annunciator.

**Description:** E-107 single-gang Emergency Stations feature satin finished stainless steel faceplates with silk-screened designations. They may be flush mounted on standard outlet boxes with single-gang rings, or surface mounted on Wiremold 5748 or equal with a depth requirement of 1 3/4".

### **Engineering Specifications**

The contractor shall furnish and install the CORNELL E-107 Emergency Stations as indicated on the plans. Faceplates shall be satin-finish stainless steel with silk-screened designations. Call indicator shall be red LED and be replaceable from rear of unit. Incandescent lamps are not acceptable. Stations shall be mounted on standard outlet boxes with single-gang rings or Wiremold 5748 or equivalent.

