



CORNELL

Emergency Response Systems

E-108A Push On/Twist Off Emergency Station



E-108A

***The CORNELL E-108A
Emergency Call Station
provides large mechanical
latched button.***

1-800-558-8957

Operation: Pushing the button on the E-108A activates a call for help confirmed by a red LED. To cancel the call, twist the push-button to the right.

Description: E-108A stations feature single-gang stainless steel faceplate with silk-screened designations. The E-108A has a "Mushroom" push-button with mechanical latching. Push on/twist off. They may be flush mounted on standard outlet boxes with single-gang rings, or surface mounted on Wiremold 5748 or equal with a depth requirement of 1 3/4". The activator is oil tight. Momentary switching is available.

ENGINEERING SPECIFICATIONS

The contractor shall furnish and install the *CORNELL* E-108A Emergency Station as indicated on the plans. Faceplate shall be brushed stainless steel, with epoxy silk-screened designations. "Mushroom" button shall be minimum of 1 1/2" in diameter. Call indicator shall be a red light emitting diode. The Emergency Station shall fit on a standard single gang plaster ring or Wiremold 5748 (for surface mounting) or equal. Minimum depth shall be 1 3/4".

CORNELL COMMUNICATIONS, INC.

Milwaukee, Wisconsin USA - 800-558-8957 - 414-351-4660 - Fax 414-351-4657
www.cornell.com - sales@cornell.com

