



# CORNELL

Emergency Response Systems

## L-101, L-102 and L-103 Corridor Lights



Silk-screened dome covers

L-101



### UL-Listed CORNELL

**Corridor Lights may be tailored precisely to meet any institution's corridor or zone indicator needs.**

**Also available on multiple gang plates.**

**1-800-558-8957**

**Configurations:** Available with one, two or three lamps and a full range of optional silk-screened designations. CORNELL Corridor Lights feature translucent wedge-shaped covers in red or white. Specify one, two or three lamp.

**Mounting:** All models mount on standard, single-gang boxes or plaster rings, with a required depth of 1 inch.

**Maintenance:** Dome covers are easily removed from the front, for simplified lamp replacement.

**Option:** Also available are 1, 2 or 3 lamps on any 1 to 6 gang plate.

### ENGINEERING SPECIFICATIONS

The contractor shall furnish and install the CORNELL Series 4000 Corridor Lights with one (L-101), two (L-102) or three (L-103) lamps. The domes shall be (red) or (white), with optional designations silk-screened on the surface. The stainless steel faceplates shall mount on a standard, single-gang electrical wall box or single-gang plaster ring, with external connection achieved via pigtails. The dome covers shall be removable from the front for easy replacement of the lamps.

