



CORNELL

Emergency Response Systems

SW-106 and SW-110 Call Cords



SW-106
(shown)

Reliable, repeatable performance is the hallmark of UL-listed CORNELL Call Cords.



1-800-558-8957

Operation: The momentary contact initiates a signal to the associated Nurse Call annunciators.

Description: A shockproof, plastic housing holds the cord's momentary contact push button operator, connected to a vinyl-covered cord six feet (SW-106) or ten feet (SW-110) long. The right-angle plug is molded to the cord for long life. Bedding clips are included.

Maintenance: The entire assembly will withstand sterilizing and routine washing.

Warnings: The call cord's pendant is not intended for use in oxygen atmospheres.

Custom lengths available.

ENGINEERING SPECIFICATIONS

The contractor shall furnish and install CORNELL Call Cords for use with the CORNELL Nurse Call System. The white polyvinyl cables shall be six feet (SW-106) or ten feet (SW-110) long and be attached to the molded plastic housing enclosing momentary contact push buttons. The entire apparatus shall be shockproof, and must withstand normal washing and sterilization. Right angle phone plugs and bedding clips shall be included. The call cord pendant is not intended for use in oxygen atmospheres.

CORNELL COMMUNICATIONS, INC.

Milwaukee, Wisconsin USA - 800-558-8957 - 414-351-4660 - Fax 414-351-4657
www.cornell.com - sales@cornell.com

