



CORNELL

Emergency Response Systems

B-111, B-113 and B-122 Bedside Stations



B-111



B-113



B-122



UL-listed CORNELL Bedside Stations let you tailor your Nurse Call Systems precisely to the application at hand.

1-800-558-8957

Components:

UL-listed CORNELL Bedside Stations may be equipped with one or two jacks (B-111, B-122) for use with CORNELL Call Cords, or furnished with push button operations (B-113). Red LED's indicate calls placed. Calls may be cancelled at the touch of a button. Removal of call cord plug from station indicates a call at the system's annunciator panel.

Mounting:

The satin-finish stainless steel faceplates may be flush mounted on standard outlet boxes with single-gang rings. The plates may also be surface mounted with Wiremold 5748 or equivalents. Total depth required is 1 3/4".

Engineering Specifications

The contractor shall furnish and install Cornell Bedside Stations as indicated on the plans. The stations shall be equipped with (1) (2) jacks for use with CORNELL Bed Cords or with push buttons, and with red LED call placed indicators and cancel switches. Removal of bedside cord plug shall appear as a call on the annunciator panel. Satin-finish stainless steel faceplates shall have silk-screened designations clearly marked. Indicator voltage shall be 24 volts DC. Wall boxes shall be standard outlet boxes with single- or double-gang covers.

CORNELL COMMUNICATIONS, INC.

Milwaukee, Wisconsin USA - 800-558-8957 - 414-351-4660 - Fax 414-351-4657
www.cornell.com - sales@cornell.com

