



CORNELL

Emergency Response Systems

E-114, E-114-1 and E-114-3 Emergency Station

E-114 &
E-114-1



E-114-3



**You can count on
CORNELL's UL listed
Emergency Stations for
long-term dependability.**

1-800-558-8957

Application: CORNELL E-114, E-114-1 and E-114-3 are used as a bedside or emergency station in a single status system.

Operation: Pulling the six-foot nylon cord on CORNELL's Emergency Station activates a call for help. The E-114-3 also has a LED light to confirm call placement. To cancel the call, slide the switch to the off position.

Description: E-114, E-114-1 & E-114-3 Emergency Stations feature satin finished stainless steel faceplates with silk-screened designations. They may be flush mounted on standard outlet boxes with single-gang rings, or surface mounted on Wiremold 5748 or equal with a depth requirement of 1 3/4".

Field wiring terminations are wire leads.

The E-114, E-114-1 and E-114-3 have DPDT contacts and pigtail wires. The E-114 has four; the E-114-1 has seven and the E-114-3 has eight pigtail wires.

Engineering Specifications

The contractor shall furnish and install these CORNELL Emergency Stations as indicated on the plans. Faceplates shall be satin-finish stainless steel with silk-screened designations.

Calls in progress can be cancelled by moving the switch to off position. (A red LED on the E-114-3 indicates calls in progress). Stations shall be mounted on standard outlet boxes with single-gang rings or Wiremold 5748 or equivalent.

CORNELL COMMUNICATIONS, INC.

Milwaukee, Wisconsin USA - 800-558-8957 - 414-351-4660 - Fax 414-351-4657
www.cornell.com - sales@cornell.com

