



CORNELL

Emergency Response Systems

E-144 Emergency Station Single Status Momentary



***You can count on our UL
Listed Emergency Stations
for long-term dependability.***

1-800-558-8957

Application: For use as a bedside or emergency station in a single status system.

Operation: Pulling the six-foot nylon cord on the E-144 activates the momentary switch on the emergency station placing a call for help.

Description: The Emergency Station features satin finished stainless steel faceplates with silk-screened designations. It may be flush mounted on standard outlet boxes with single-gang rings, or surface mounted on

Wiremold 5748 or their equivalents, with a depth requirement of 1 3/4". Field wiring terminations are with pig-tails.

Engineering Specifications:

The contractor shall furnish and install the CORNELL E-144 Emergency Stations as indicated on the plans. Faceplates shall be satin-finish stainless steel with silk-screened designations. Stations shall be mounted on standard outlet boxes with single-gang rings or Wiremold 5748 or equivalent.

CORNELL COMMUNICATIONS, INC.

Milwaukee, Wisconsin USA - 800-558-8957 - 414-351-4660 - Fax 414-351-4657
www.cornell.com - sales@cornell.com

