



CORNELL

Emergency Response Systems

P-106 and P-116 Panic Stations



P-106



P-116

CORNELL's panic stations are ideal for use in psychiatric wards and court rooms since the call can only be cancelled at the master.

1-800-558-8957

Operation: A call is placed by pressing the momentary button. Calls must be reset remotely.

The switch on the P-106 is flush to the plate and covered by a rubber membrane, making the P-106 water and dust resistant. The P-116 has a protruding red button.

Description: The (P-106) (P-116) stations feature satin finished stainless steel faceplates with silk-screened designations. The UL Listed switch is rated at 15 amperes @ 125 volts AC. Momentary action switch can be wired for NORMALLY OPEN or NORMALLY CLOSED function. Three female SLIP-ON connectors are provided.

The P-106 is ideal for use in psychiatric wards to active remote electronics.

The P-106 is also suitable for use in dusty or damp environments.

Engineering Specifications:

The contractor shall furnish and install the CORNELL (P-106) (P-116) panic station as indicated on the plans. Faceplates shall be satin-finish stainless steel with silk-screened designations. Stations shall be mounted on standard outlet boxes with single-gang rings (minimum depth of 1 $\frac{3}{4}$ or Wiremold 5748 or equivalent).

CORNELL COMMUNICATIONS, INC.

Milwaukee, Wisconsin USA - 800-558-8957 - 414-351-4660 - Fax 414-351-4657
www.cornell.com - sales@cornell.com

