



**CORNELL**

Emergency Response Systems

## Z-103 Triple Status Zone Light



**Z-103**

**The CORNELL Z-103  
Zone Light telegraphs  
the need for help  
instantly.**

**1-800-558-8957**

**Call Indications:** Independent lamps provide a steady white light for normal, a pulsing green light for third priority or flashing red light for an emergency. Provisions for connection to CORNELL L-103 remote corridor lights are included.

**Finish and Mounting:** Translucent white plastic lens on stainless steel plate, for mounting on a standard, single-gang plaster ring or 5748 Wiremold box. Total depth is 1 inch.

### **Engineering Specifications:**

The contractor shall furnish and install CORNELL Zone Lights (Z-103) to provide visual indication of normal and emergency calls within a zone. Flashing red light shall indicate an emergency; steady white light a normal call; pulsing green a third priority. The lights shall operate independently. The stainless steel faceplate shall mount in a single-gang electrical box or plaster ring, and shall include a provision for connecting a remote corridor light (CORNELL L-103).

10/03

**CORNELL COMMUNICATIONS, INC.**

Milwaukee, Wisconsin USA - 800-558-8957 - 414-351-4660 - Fax 414-351-4657  
www.cornell.com - sales@cornell.com

