



Pullcord Emergency Stations, Economy

HWN7652UA (Standard model) / HWN7657AA (Water-resistant model)

Description

The Economy Pull Cord Emergency Stations are single-gang, wall-mounted units, with a nylon cord allowing a call for help to be placed from a standing, sitting or prone position. The cord may be pulled from any angle to place a call, which lights the station LED and activates other devices, such as a Dome Light, Duty Station, Annunciator Panel, or Nurse Console. Pressing the RESET switch on the station cancels the call. The water-resistant model provides safe, dependable operation in shower areas. These units are installed in conjunction with an addressable Patient Station or Smart Station.



Features

- Simple RESET switch
- Luminous glow in the dark pendant
- Designed for simple installation and maintenance
- Distinct Call Annunciation - Flexible system configuration provides distinct annunciation throughout the system to alert the staff to high priority calls. Calls placed from Emergency Stations must be canceled only at the point of origin, assuring a visit by the nurse.

Technical Data

Input Power: 12 VDC (0 mA standby, 12 mA with LED on)
Signal Ground: (Data and logic reference)

Architect's Specifications

HWN7652UA

The Pull Cord Emergency Stations (model HWN7652UA and model HWN7657AA) shall be single-gang, wall-mounted call devices, on a brushed stainless steel faceplate. They shall be used in conjunction with an addressable station, such as a Single Patient Station, Dual Patient Station, Smart Station, etc. The front panel of the Pullcord Station shall include the following: A 72" nylon cord with luminous pendant, a RED call LED indicator and a RESET slide switch. A rubber gasket is included on the water resistant model (HWN7657AA) to protect the station from moisture. A 5-position quick-disconnect, insulation-displacement type connector shall be provided to terminate field-installed power and control lines.

Wall Box

Each Pullcord Emergency Station requires a standard one-gang electrical backbox, 3 1/2" deep minimum.

Rev 4/05

CORNELL COMMUNICATIONS, INC.

Milwaukee, Wisconsin USA - 800-558-8957 - 414-351-4660 - Fax 414-351-4657
www.cornell.com - sales@cornell.com

