



# Push Button Station with Audio, Economy

HWN7670UC 2G Audio-Visual, Single Bed, Pushbutton

## Description

The Push Button Station, Economy offers multiple call levels in a low cost traditional push button package. Each wall-mounted device includes an answer LED indicator, a call LED indicator and a RESET button. The stations contain a bi-directional speaker/microphone for voice communications between resident and staff. An easy-to-clean, rugged, stainless steel faceplate provides lasting, professional style.

Installation is straightforward and compatible with other resident stations used with the Call System. The various auxiliary call stations, such as the Pushbutton Emergency, Pull Cord Emergency, or Code Blue can be used in conjunction with the Economy series.



HWN7670UC

## Features

- Fully programmable to address requirements including 4 input and 4 output channels
- Quick-disconnect terminals designed for simple installation and maintenance

## Model Identification

HWN7670UC Economy patient station with voice, 2-gang with pushbutton, mounted on a stainless steel faceplate

## Technical Data

Input Power: 12 VDC, 1 mA DC standby current per station  
Output Power: 24 VDC, 250 mA DC max per output channel

## Architect's Specifications

Model HWN7670UC shall be 2-gang, wall mounted devices with voice and include a brushed stainless steel faceplate. HWN7670UC shall have a pushbutton switch for placing a call.

- The front panel shall include the following:
- One RESET button
  - One station speaker/microphone
  - One call LED indicator

The station shall include a dip switch for selecting one of 32 unique polling addresses. It shall also include terminations for connection to auxiliary input devices, such as bath emergency, pushbutton emergency, staff locator, or code blue stations. It shall also provide output terminals for connection to dome light indicators. Quick-disconnect, insulation-displacement type connectors shall be provided to terminate field-installed power, control and audio lines.

## Wall Box

Model HWN7670UC shall require a standard 2-gang x 3 1/2" masonry box, or equivalent.

Rev 4/05

**CORNELL COMMUNICATIONS, INC.**

Milwaukee, Wisconsin USA • 800-558-8957 • 414-351-4660 • Fax 414-351-4657  
www.cornell.com • sales@cornell.com

