



Visual Stations, Economy

HWN7668UC 2G Visual, Call Cords, one receptacle

HWN7678UC 3G Visual, two receptacles

Description

The Visual Stations offer multiple call levels in a low cost package. Each of the wall-mounted devices include an answer LED indicator, a call LED indicator for each input receptacle, and a RESET button. The input receptacles accept any one of the existing Call Cords: model HAN7608UA, HAN7609UA, or HAN7610UA. An easy-to-clean, rugged, stainless steel faceplate provides lasting, sanitary, professional style. Installation is straightforward and compatible with other patient stations used with the Nurse Call System. The various auxiliary call stations, such as the Pushbutton Emergency, Pull Cord Emergency, or Code Blue can be used in conjunction with the Economy series. Output devices such as: duty stations, annunciator panels, and dome lights are also compatible.



HWN7668U

Features

- Fully programmable to address specific needs of the customer including 4 input channels & 4 output channels
- Seven call/output levels (Routine, Remind, Priority, Bath, Emergency, Code Blue, Staff In)
- Safety disconnect call cord will place call when removed
- Quick-disconnect terminals for simple installation and maintenance

Model Identification

HWN7668UA Economy visual patient station, 2-gang with phonojack receptacle, mounted on a stainless steel faceplate

HWN7678UC Economy visual patient station, 3-gang with two phono jack receptacles, mounted on a stainless steel faceplate

Technical Data

Input Power: 12 VDC, 1 mA DC standby current per station; Output Power: 24 VDC, 250 mA DC max per output channel

Architect's Specifications

HWN7668UC shall be a 2-gang, wall mounted device and include a brushed stainless steel faceplate. It shall have one call LED, one phono jack receptacle to service one or two beds, and a RESET button. HWN7678UC shall be a 3-gang, wall mounted device and include a brushed stainless steel faceplate. Model HWN7678UC shall have two phono jack receptacles for servicing two beds with individual readouts at the annunciator panel, two call LED's, and a RESET button. The phono-jack call cord receptacles shall accept the following call cord device: HAN7608UA - single call cord. The station shall include a dip switch for selecting one of 32 unique polling addresses. It shall also include terminations for connection to auxiliary input devices, such as bath emergency, pushbutton emergency, staff locator, or code blue stations. It shall also provide output terminals for connection to dome light indicators. Quick-disconnect, insulation-displacement type connectors shall be provided to terminate field-installed power, control and data lines.

Wall Box

Model HWN7668UC shall require a standard 2-gang X 3 1/2" deep masonry box, or equivalent.

Model HWN7678UC shall require a standard 3-gang X 3 1/2" deep masonry box, or equivalent.

CORNELL COMMUNICATIONS, INC.

Milwaukee, Wisconsin USA - 800-558-8957 - 414-351-4660 - Fax 414-351-4657
www.cornell.com - sales@cornell.com

Rev 9/05

