



CORNELL

Emergency Response Systems

E-105 Emergency Station Toggle Switch, Dual Status



E-105

You can't always take dependability for granted. With UL-listed CORNELL Clinical Room Stations, you can.

1-800-558-8957

Applications: CORNELL Clinical Room Stations may be used as nurse follower, clinical annunciator, or emergency call stations.

Components: Each Clinical Room Station features a red LED indicator to signal calls and a toggle switch, mounted in a single-gang, satin-finish stainless steel plate. Designations are epoxy silk-screened on the surface.

Mounting: The stations may be flush mounted in single-gang plaster ring on standard outlet boxes, or surface mounted with Wiremold 5748 or equivalents. Depth required is 1 3/4".

Engineering Specifications

The contractor shall furnish and install Cornell Clinical Room stations (E-105) for use as clinical annunciator, emergency call or nurse follower stations. Faceplates shall be satin-finish stainless steel with silk-screened "call placed", "on", and "off" designations clearly marked. Call indicator shall be red light emitting diode. Incandescent lamps are not acceptable. On-off switch shall be toggle. For flush mounting, back box shall be standard outlet box with single-gang plaster ring; for surface mounting, Wiremold 5748 or equivalent.

CORNELL COMMUNICATIONS, INC.

Milwaukee, Wisconsin USA - 800-558-8957 - 414-351-4660 - Fax 414-351-4657
www.cornell.com - sales@cornell.com

