



**CORNELL**

Emergency Response Systems

## TR-P100 Mobile Transmitter



**AURA**  
by CORNELL

### TR-P100 – MOBILE TRANSMITTER

#### Product Description:

The TR-P100, a single-button, water resistant transmitter, is a small, light-weight, versatile product. It can be worn on a belt or on a lanyard around the neck. It comes with a neck cord and can be easily converted to a belt clip. An optional wristband allows the pendant to be worn on the wrist or arm. By pressing and holding the single button, an alarm is activated. It is ideal for almost any environment and weighs only 1.4 ounces.

#### Features:

- Fully supervised wireless 900MHz frequency transmitter which helps provide true security and reliability.
- A single-button design with “press and one-second hold” activation makes the product very easy to use and helps to prevent false alarms.
- Low battery warning before battery depletion – two-week warning allows for scheduled battery replacement. Battery life is 1 – 2 years (typical).
- Flashing LED indicator during alarm activation which shows that the transmitter is working.
- Includes a customer-replaceable 3V lithium button-type battery.
- Especially suited for assisted living installations.

#### Specifications:

- Dimensions: 2.2” x 1.9” x 0.72”

