



Sentinel V2 System Components

MODEL #	DESCRIPTION:	PRODUCT IMAGE:
Main Components:		
SCM-4825	System main head-end unit. Supports up to 8 Call Station or Base Station devices. Includes (1) RJ45 SFP adapter, (1) 1ft patch cable, (1) 120VAC power cord, (2) mounting brackets and (1) USB drive.	
A-4800BS	Base Station IP phone. Answer incoming emergency pushbutton calls / displays system statuses. Includes stand for desk-mounting. Metal enclosure for wall-mounting sold separately (BB-48SM).	
4800VS-3	Call Station device (3-gang). Activates an emergency request for help. Includes (x4) mounting security screws.	
Add-on Components:		
POTS-4800S	POTS modem enables system to use an analog telephone line when dialing out to a 24/7 monitoring location. Includes the modem, power cord, and ethernet patch cable to connect to the SCM-4825 .	
ES-4808S	24VDC, 8-port PoE switch to accommodate more devices. Includes 24VDC, 3A power supply and (2) 12VDC, 7Ah batteries. Enclosures for power supply and expansion mount adjacent to each other.	
ES-4808S-65	24VDC, 8-port PoE switch to accommodate more devices. Includes a 24VDC, 10A power supply. Large battery boxes included. Larger 7710-065 batteries (12VDC, 55+Ah) are sold separately.	
SN-xxxx	Various signage options for your AOR / ARA system. Electrical and photoluminescent signs offered.	
HW-02	Rack-mount hardware to mount the SCM-4825 head-end unit into a 3U networking rack space. Includes (4) cage nuts and Screws.	
SCM-4825 (Head-end) Battery Backup Options:		
B-4825-7	Pair of 12VDC, 7Ah batteries w/ metal enclosure used for short-term battery backup <u>only</u> for the SCM-4825 unit. Includes (2) 12VDC batteries, metal enclosure, fuse kit and battery shelf w/ grommet.	
B-4865	Pair of standing battery boxes for the 7710-065 batteries shown below. This includes a fuse kit for wiring.	
7710-065	12VDC, 55+Ah battery for long-term battery backup. (x2) Batteries provide extended backup power for the main SCM-4825 unit or any ES-4808S-65 Expansion Switch. Battery boxes sold separately.	
Enclosure / Trim Ring:		
BB-48SM	Locking metal enclosure backbox with view window for wall-mounting the A-4800BS Base Station phone. Optional BB-48TS trim ring available for semi-flush mounting sold separately.	
BB-48TS	Semi-flush trim ring for the BB-48SM enclosure. Used to mount the BB-48SM recessed into a wall.	
7330-108R	Surface-mount enclosure included with the B-4825-7 and ES-4808S . Dimensions are 12"W x 12"H x 4"D.	