

Base Station Enclosure BB-48SP



BB-48SP

Description: The Area of Refuge Base Station Enclosure (BB-48SP) is an optional enclosure to secure the base station. The BB-48SP is plastic with a clear door that folds down with a removable chain so the door can either come to 90 degrees from the wall or hang down so it is parallel to the wall. The BB-48SP also includes lockable clasps to secure the base station in a public location.

Operation: When a call is activated, user shall unlock the box and unhook the 2 latches included at the top of the enclosure.

Mounting: Surface mount with screws into the rear of the box. Base Station mounts with included brackets.

Engineering Specifications: The contractor shall furnish and install the CORNELL BB-48SP as indicated on the plans. Enclosure shall be Polycarbonate Gray with a clear cover. The enclosure shall be mounted with the clasps at the top to allow the activation of a call to be answered by easily undoing the clasps and allowing the enclosure to stay open without any additional actions by the user.

Technical Information:

- Enclosure Plastic, Polycarbonate Gray, Clear Cover
- Cover Included
- Physical dimensions: 14.580" L x 12.580" W (370.33mm x 319.53mm) X 7.380" (187.45mm)
- Operating Environment: -40 °F to 185 °F

