

POTS Network Adapter POTS-4800S



POTS-4800S

Description: The POTS Network Adapter (POTS-4800S) is required to hook up the Sentinel Area of Refuge Main System (CM-4800S) to a POTS telephone line, allowing the Area of Refuge Call Station (4800VS) to call an offsite to a pre-programmed emergency number (Outside Monitoring not Included).

Operation: The Sentinel Area of Refuge system call off-site; POTS, VoIP, SIP are supported. The POTS Network Adapter is required for the POTS line to be connected to the system.

Mounting: Mounted using included Polyurethane Foam Mounting Tape. Mounts to a 1U 8" networking rack shelf which shall mount inside the Main System Box (CM-4800S).

Connections: Includes CAT5E patch cable for connection to the CM-4800S system network and a 12VDC power cable adapter. The contractor shall furnish and install an analog/POTS RJ11 telephone line to be connected to the POTS-4800S device.

Engineering Specifications: The contractor shall furnish and install the *CORNELL* POTS-4800S POTS Network Adapter as indicated on the specification when a POTS line is used for off-site monitoring. The contractor shall install the POTS Network Adapter per the instructions included.

Technical Information:

- Power Requirements: Use the included 12VDC adapter for power.
- Operating Environment: -40 °F to 185 °F
- Physical Dimensions: 3.56 x 1.14 x 5.14 inches