

Panic Station P-120



Description: The (P-120) panic station features satin finished stainless steel faceplates.

Operation: A call is placed by pressing the momentary button. Calls must be reset remotely.

Mounting: The satin finish stainless steel faceplate may be flush mounted on a standard outlet box with single-gang plaster ring, or surface mounted on a Wiremold 5748 or equivalent. Field wiring terminations are (2) 22 AWG wire leads connected to the N.O. contacts

Engineering Specifications: The contractor shall furnish and install the CORNELL (P-120) panic station as indicated on the plans. Faceplates shall be satin-finish stainless steel and shall be mounted on standard outlet boxes with single-gang rings (minimum depth of 1 $\frac{3}{4}$ " or Wiremold 5748 or equivalent).

Technical Information:

- Operating Environment: 50-120°F Indoor Non-condensing
- Physical Faceplate Dimensions: 4 $\frac{1}{2}$ "H x 2 $\frac{3}{4}$ "W (Standard 1 Gang)
- Mounting: Single-Gang back box with 1 $\frac{3}{4}$ " minimum depth
- Wiring: (2) #22 AWG 6" wire leads connected to the N.O. contacts