



NOTES:
 ALL WIRE SIZES NOT SPECIFIED ARE 22AWG. OR HEAVIER. IT IS RECOMMENDED THAT EACH GREEN GROUND SCREW, GREEN GROUND WIRE, AND GREEN GROUND SCREW TERMINAL ON ALL CALL STATIONS (LABELED "G") BE CONNECTED TO EARTH GROUND, 18AWG. MINIMUM WIRE SIZE.

ALL STATION MODEL DESIGNATIONS MAY VARY. GENERALLY, THE FIRST DIGIT IN THE DESIGNATION IS THE GANG PLATE SIZE. EXAMPLE:
 B-111 SINGLE GANG PLATE.
 B-211 DUAL GANG PLATE.
 B-311 THREE GANG PLATE
 ALTHOUGH THE PLATE SIZES MAY VARY, THE TERMINAL DESIGNATIONS AND CONNECTIONS REMAIN THE SAME.

MINIMUM 3' DEPTH ELECTRICAL BDX REQUIRED.



CORNELL Communications, Inc.
 sales@cornell.com 414-351-4660
 Web: www.cornell.com 414-351-4657(fax)

DATE: DECEMBER 16, 2013
TITLE: SINGLE STATUS SYSTEM

SYSTEM: 4000 NURSE CALL
DRAWING # 90003-13 D4000W-1A