



## Push Button Station with Audio, Economy HWN7670UC



**Description:** The Push Button Station, Economy offers multiple call levels in a low cost traditional push button package. Each wall-mounted device includes an answer LED indicator, a call LED indicator and a RESET button. The stations contain a bi-directional speaker/microphone for voice communications between resident and staff. An easy-to-clean, rugged, stainless steel faceplate provides lasting, professional style. Installation is straightforward and compatible with other resident stations used with the Call System. The various auxiliary call stations, such as the Pushbutton Emergency, Pull Cord Emergency, or Code Blue can be used in conjunction with the Economy series.

**Operation:** When used with a Cornell System, the Push Button Station initiates a call when button is pressed. Reset provided with reset button.

**Mounting:** Model HWN7670UC shall require a standard 2-gang x 3 1/2" masonry box, or equivalent.

**Engineering Specifications:** Model HWN7670UC shall be 2-gang, wall mounted devices with voice and include a brushed stainless steel faceplate. HWN7670UC shall have a pushbutton switch for placing a call.

The front panel shall include the following:

One RESET button

One station speaker/microphone One call LED indicator

The station shall include a dip switch for selecting one of 32 unique polling addresses. It shall also include terminations for connection to auxiliary input devices, such as bath emergency, pushbutton emergency, staff locator, or code blue stations. It shall also provide output terminals for connection to dome light indicators. Quick-disconnect, insulation-displacement type connectors shall be provided to terminate field-installed power, control and audio lines.

### Technical Information:

- Power Requirements: 12VDC
- Operating Environment: 50-120°F Indoor Non-condensing
- Physical Faceplate Dimensions: 4 1/2 "H x 4 1/2 "W (2 Gang)
- Mounting: Standard 2-Gang Back Box
- Wiring: #22 AWG Minimum