

Wireless Pull Cord Station TR-ST100E



Description: The TR-ST100E is a surface mounted pull cord station with a six foot pull cord. A reset switch is located on the side and the call can only be reset at the station.

Operation: When used with Cornell System, this device provides wireless emergency on-call assistance. Ideal for hospitals, medical specialty clinics, nursing homes, and assisted living facilities.

Mounting: Includes mounting bracket for wall mounting

Engineering Specifications: The contractor shall furnish and install the CORNELL TR-ST100E Wireless Pull Cord Station as indicated on the plans. Pull Cord Station shall be programmed to AURA 2.0 following specifications. Pull Cord shall be mounted with provided bracket.

Technical Information:

- Dimensions: 3.5" x 1.7" x 0.9"
- Power: 3.0V Lithium battery
- Battery Replacement: Duracell DL123A lithium battery
- Battery Life: 4-5 years
- Operating Environment: 50-120°F Indoor Non-condensing