



Bathroom/Urgent Call Station E-704



Description: The E-704 Bathroom/Urgent Call Station provides call annunciation from a bathroom associated with a patient station. It also provides call annunciation from a common area restroom or staff call location when used with the common area call station.

The E-704 is constructed with a rugged 1- piece fire-retardant ABS plastic faceplate, and is waterproof for use in bathrooms. Switch can be pressed down to call or activated with the pullcord.

Operation: A call from the bathroom pullcord will annunciate an urgent tone and flashing LED on the master station, indicating the location of the call. The duty station will receive the call tone and flashing LED, but does not indicate the calling location.

When the E-704 is connected to a common area call station, the associated lamp on the common area call station will flash, and the location will be annunciated on the master station.

The call must be cancelled at the calling location by moving the call switch to the upward position.

Mounting: Unit shall flush mount into a standard 1-gang box.

Engineering Specifications: Bathroom/urgent call station shall be Cornell model E-704, equipped with locking vertical slide call switch, nylon cord with pendant, and LED "call placed" indicator.

Call station shall be waterproof, constructed with 1- piece rugged fire-retardant ABS plastic. Nylon cord shall be durable, and able to activate a call-in signal by pulling the cord in any direction.

E-704 shall be used to place an urgent call associated with the patient station or common area call station. Call shall be reset only at the calling station by moving the call switch to the upward position. Wiring shall be 3 conductors, run from associated patient station or common area call station. Cable size greater than 22AWG shall not be required.

Unit shall flush mount into a standard 1-gang box.

Equipment shall be UL 1069 listed.

Technical Information:

- Power source: From call station
- Mounting: 1-gang box, UL listed
- Wiring: 3 conductors to associated call station
- Material: High impact ABS fire-retardant plastic
- Nylon cord
- Color: White, with red call switch
- Dimensions: (H x W x D): 4-1/2" x 2-13/16" x 1-3/4"
- Certification: UL 1069 Listed, C-UL Canadian Standard C22.2