

## Transmitter, Wireless Mobile Pendant TR – P100E



TR-P100E

**Description:** The TR-P100E is a single button; water resistant pendant is our smallest, lightest, and most versatile pendant. Weighing less than 1.4oz, it comes with a neck cord and belt clip and can be easily converted by the end user. With the single-button, one-second press and hold activation, and a compact design, it is ideal for assisted living installations. It features a fully supervised radio link to help ensure reliability. Wristband also available.

**Operation:** When used with Cornell System, this wireless device provides immediate emergency call assistance.

**Engineering Specifications:** The contractor shall furnish and provide the CORNELL TR-P100E Wireless Mobile Transmitter as indicated on the plans. Mobile Transmitters shall be programmed to AURA 2.0 following specifications. Mobile transmitter shall be provided with neck cord and belt clip.

### Technical Information:

- Dimensions: 2.2" x 1.9" x 0.72"
- Power: 3.0V Lithium
- Battery Replacement: 3.0 volt Renata CR2450N lithium coin cell battery
- Battery Life: Up to 1-2 years
- Operating Environment: 50-120°F Indoor Non-condensing