

Room Status Lights L Series



Description: Cornell's L Series Light Status lights offer 1-6 colors (Red, Green, Blue, Amber, Yellow, or White) to indicate the status of one of Cornell's Light Status Series room status stations.

Operation: The station will wire to one of Cornell's S series stations to turn on the incandescent lamp when the station is in "call" mode.

Mounting: The satin finish stainless steel faceplate with silk-screened designations may be flush mounted on a standard outlet box with single-gang plaster ring, or surface mounted on a Wiremold 5748 or equivalent.

Engineering Specifications: The contractor shall furnish and install Cornell's L Series Room Status Lights at the noted locations for use as indication for S series stations. Faceplates shall be satin-finish stainless steel. Indicator lamps shall be specified colors to coincide with S series stations. For flush mounting, back box shall be standard outlet box with single-gang plaster ring; for surface mounting, Wiremold 5748 or equivalent.

Technical Information:

- Power Requirements: 24VDC
- Operating Environment: 50-120°F (0-60°C) Indoor Non-condensing
- Physical Faceplate Dimensions: 4 ½ "H x 2 ¾ "W (1 Gang)
- Mounting: Single-Gang back box
- Wiring: Minimum 22AWG