



# **VersaPage™**

Modular Paging Interface

Complete Solution for Direct Messaging to Staff When Emergencies Arise or Assistance is Needed.



## **Fast Patient Response**

In a medical office fast and efficient response is vital to any patient need and emergency situation. *VersaPage™* can instantly notify in-house pagers, send a text message to a cell phone or send an e-mail to an individual or group all at once enabling the appropriate response.

## **Expand the System**

The system can fit the needs of any building by connect up to eight slaves to the master unit. The master unit has a capacity of 64 calling devices with a maximum of 576 when all eight slaves units are connected. Put a slave unit on every floor or wing to keep all calls well organized.

## **Keep Records of Every Call**

When a call is made it can be stored for multiple days in the system's data log. Different types of reports can be made by selecting search parameters such as room number, date, and type of call. All records are kept in the master unit on an easily removable memory card.

## **Features & Benefits:**

- Easy & Quick Installation
- Minimal Wiring Required
- Simple to Operate and Train Staff
- Multiple Product Integration
- Discrete Communication
- Existing Systems can be Upgraded
- Flexible System Design
- Saves Valuable Response Time

---

### **CORNELL COMMUNICATIONS, INC.**

Milwaukee, Wisconsin USA • 800-558-8957 • 414-351-4660 • Fax 414-351-4657  
www.cornell.com • sales@cornell.com





## Newest Features

- Data Logging & Documentation
- *VersaPage*™ Desktop PC Paging System Software\*  
Any desktop PC computer can instantly notify in-house pagers, send a text message to a cell phone or send an e-mail to an individual or group all at once!

\*Desktop System designed for Windows XP and Vista only. Requires Outlook for e-mail or text messages and will not function on thin network client systems

## System Components

MODEL	# DESCRIPTION
PI-9064U	Paging Interface Universal - The paging interface unit has the ability to monitor signal type, location and event code while sending information to a database and transmitter. Reporting and programming are accessed using a web browser program, connecting to an IP address. 12 VDC power and data cable are included.
TR-9010-W2	2 Watt Paging Transmitter including 1/4 wave antenna providing from 0.25 to 0.5 miles radius of horizontal coverage. Includes RS-232 cable.
TR-9010-W5	5 Watt Paging Transmitter including 1/4 wave antenna providing from 0.5 to 1.0 miles radius of horizontal coverage. Includes RS-232 cable.
PP-9000-AW2	Pocket Pager for 2 Watt System
PP-9000-AW5	Pocket Pager for 5 Watt System
SF-9010	<i>VersaPage</i> ™ Desktop PC Paging System Software for one (1) PC
SF-9010N	<i>VersaPage</i> ™ Desktop PC Paging System Software for MULTIPLE PC's

Choose *VersaPage*™ for your facility today.  
Whether you wish to add it to your current system or include paging as part of a new system, **CORNELL** can meet your unique requirements.

For more information about *VersaPage*™, or the complete line of Cornell products, visit [www.cornell.com](http://www.cornell.com) or call us at (800)558-8957.

### CORNELL COMMUNICATIONS, INC.

Milwaukee, Wisconsin USA • 800-558-8957 • 414-351-4660 • Fax 414-351-4657  
[www.cornell.com](http://www.cornell.com) • [sales@cornell.com](mailto:sales@cornell.com)

